

1



Thread the Tam Torque through the pre-cut slots

2



Offer up to the post

3



Tighten the Tam Torque

4



Completed Installation

Equipment you will need:

- Column Plate
- 1 x Tam Torque - suitable for the size of post
- 1 x 50mm Driver Bit (C-0030)
- 1 x Ratchet Driver (C-0041)

www.signscape.co.uk
sales@signscape.co.uk

t: 01934 852888
f: 01934 852816